


4 Traffic Stats Kustom Console

Select the Stats tab and chose from Last Hour of data, Hour by Hour data, Histograms, to review data on the device. To download traffic data, select the Vehicle by Vehicle (VBV) log. Export to CSV (Excel) or Export to KSI (Kustom Traffic Count). Save the files to a location that is easy to find on your device. Connect your device to a PC to transfer files, or use the device to share the data.



	Time	Speed	Sign state
1.	02.19.19 09:19:47	28	35
2.	02.19.19 09:19:52	23	35
3.	02.19.19 09:19:56	20	35
4.	02.19.19 09:20:45	34	35
5.	02.19.19 09:20:57	28	35
6.	02.19.19 09:21:08	21	35
7.	02.19.19 09:23:52	41	35
8.	02.19.19 09:24:31	30	35

Clear table Refresh table Export to CSV Export to KSI 1 - 100 of 6345 Previous page Next page



PMD 10/12 Quick Reference Guide
KSI Part # 006-1230-10 Rev 1



006-1230-10

PMD 10/12 Quick Reference Guide

1 PMD 10/12 Front & Rear Panel Controls




www.kustomsignals.com

Sales (800) 4KUSTOM (800) 458-7866


Customer Service (800) 835-0156

2 PMD Program with Kustom Console



Username = kuser (all lower case)
Password = ksi2020 (all lower case)

From an Android or Windows device, open the Kustom Console and connect to the display. Select the Scheduler tab and chose the desired Mode from the buttons on the left. Select the number of speed thresholds, each threshold speed and the display mode for each. When finished, select “Activate Mode” and “Write to device” to program the display.



3 Display Modes

Push Button # Display Mode Description

0	Blank Display	
1	RADAR Speed	
2	RADAR Speed - Flashing	
3	Dashes (high speed blank alternative)	
4	Dashes – Flashing	
5	All 8's Display Test	
6	Posted Speed Limit	
7	Posted Speed Limit - Flashing	
8	Flashing White LED Strobe	
9	Red & Blue Light bar	